




# Corrugated Document Cases Set-up Instructions




1. Lay case flat. Make sure prominent creases are facing up




2. Fold up cover flaps




3. Fold over front cover flat and lock tabs into slots




4. Fold side panel bottom flaps flat against side panels. Loop pull-string over round tab with knot on inside of flap




5. Partially fold over front, bottom and inner panels as shown



6. Fold up side panels and slide side panel front flaps between front flaps as shown. Hold side bottom flaps flat against side panels while folding. Pull-string should be on outside of case



7. Fold front inner panel in against front panel



8. Fold side panel bottom flaps down to lock front inner panel in place